

GoldMaster

S-4700 Hoparlör Sistemleri



Kullanma Kılavuzu

HOPARLÖRLERİN KONUMU

Hoparlörleri doğru yerleştirmek çok önemlidir. Ön hoparlörlerinizi merkez hoparlörün sağına ve soluna en azından 2 metre aralıklarla yerleştiriniz. Merkez hoparlör ön yüzü size bakan televizyonun üstünde veya altında durmalıdır. Surround hoparlörleri kulaklarınızın 1 metre kadar yukarısında duracak şekilde oturduğunuz yerin arkasına yerleştiriniz.

HOPARLÖR KABLOSU

1.5 mm- 2mm çaplı yüksek kaliteli(oksijenden arındırılmış) kablo kullanınız. Kablonun plastik kaplamasının üstünde artı kutuplu kabloyu gösteren bir işaret olmasına dikkat ediniz. Bu çok önemlidir, çünkü hoparlörlerinizin kırmızı-siyah bağlantılarını yanlış yapmanız sonucunda faz kayması oluşabilir. +artı kutbun + ya bağlanmasına dikkat ediniz. Yanlış bağlantı aletin bas tepkisini azaltacak ve hoparlörlerin ses özelliklerini değiştirecektir.

BANANA FİŞ KONEKTÖRLERİ

Ön hoparlörlerin uçlarında Banana fiş konektörleri bulunur. Firmanızdan doğrudan doğruya kabloun ve fişin uçlarındaki soketlere takılmış olduğu Banana fişleri satın alabilirsiniz. Ucun altında geniş çaplı bir delik vardır. Eğer Banana fişlerini kullanmıyorsanız kaplamayı kablodan 15 mm kadar kesin, ucun vidalarını sökün ve kabloyu deliğin içinden geçirerek itin. Ucun gergin bırakın. Tüm uçların gergin olmasına özen gösterin. Gevşek olmaları durumunda statik sese neden olabilirler.

STANDART HOPARLÖR BAĞLANTISI

Alıcıdaki kırmızı +'yı hoparlördeki kırmızı +'ya, siyahı da aynı şekilde siyaha bağlayın. Merkez ve arka surround hoparlörleri alıcınızın talimatlarına uygun olarak yerlerine bağlayın.

CİHAZIN KULLANIM ÖMRÜ 10 YILDIR.



Üretici Firma

AYYILDIZ ELEKTRİKLİ EV EŞYALARI İMALAT VE PAZARLAMA A.Ş.

Adres: Halkalı cad. No:228 Sefaköy-İstanbul-Türkiye

Fax : 0212 6930224

Web : www.goldmaster.com.tr

E-mail : info@goldmaster.com.tr

Placement Of Speakers

Speaker placement is very important. You should have your front speakers at least 2 metres detach left and right of the centre speaker. The centre speaker either sits on top or under the Television facing you. The surround speakers should be placed either side slightly to the back of your seating position about half a metre above your ears.

Speaker Wire

Use good quality speaker wire (Oxygen Free Cable) around 1.5 to 2mm in diameter with a trace or marking on the plastic coating to determine which is the positive wire. This is very important, because if you connect your speakers red to black on 1 speaker you will have what we call (out of phase). You must ensure that positive + goes to positive +. If you connect the wrong way it will reduce the bass response and change the characteristics of the speakers sound.

Banana Plug Connectors

The terminals on the front speakers have Banana plug sockets. You can purchase Banana plugs from your store that fit the wire and plug directly into the sockets on the terminals. There is also a large diameter hole under the terminal. If you are not using Banana plugs cut the coating from the wire about 15mm, unscrew the terminal, push the wire through the hole and do the terminal up tight. Make sure all terminals are tight. If they are loose that can cause a static type of sound.

Standard Speaker Connection

Connect red + from your receiver to red + on the speaker and black - to black - the same way. Connect the center and rear surround speakers to the connections as shown on the Receivers instructions.